₩ Vestax LAVB FOO'

MECH.INSULATOR FOR VESTAX TURNTABLES

INSTALLATION MANUAL)

1-18-6 Wakabayashi, Setagaya-ku, Tokyo 154-0023 Japan Web:http://www.vestax.com/

Vestax Global Support support@vestax.net

Vestax Furone Support support@vestax.net

Thank you for purchasing the Vestax Original Replacement Parts; PDX mech.insulator designed for each type of turntables. Three types are produced for the

O QFO Series

O Controler ONE Series

O PDX-2000

O PDX-3000

Installing

1) Check turnatbles chassis threads before installation TT.AVB foot. The threads must be intact. Before mounting a special treat with ceramic grease. After screw the TT.AVB foot into the chassis brackets. Do not tighten fully! Check that the foot can rotate freely.




Adjustment


- 1) Place the turntable on a perfectly horizontal and solid surface.
- ②Use a spirit level to calibrate; gradually balance the turntable to the perfect horizontal position.

NOTE

Perform balancing with the plate attached.

3 After you have finished balancing the turntable, just start balancing the pickup arm, not vice versa.





raised.