



BRAND	MODEL
-------	-------

AKAI MPD18



AKAI MPD24



AKAI MPD26



AKAI MPD32



AKAI MPK25



AKAI MPK61



AKAI LPK25



AKAI LPD8



\* 本体側Adaptor必要

AKAI APC20



\* 本体側Adaptor必要

AKAI APC40



AKAI EWI-USB



BRAND	MODEL
-------	-------

ALESIS QX49



ALESIS DM10



Arturia SPARK



Allen & Heath XONE:K2



DENON DH-HC1000S



DENON DN-SC2000



ICON i-stage



Keith McMillen 12 Step



KORG nanoKey2



KORG nanoKontrol2



KORG nanoPad(2)



BRAND	MODEL	
VESTAX	PADONE	
VESTAX	VCI100	
VESTAX	VFX-1	
VESTAX	VCM600	
VESTAX	TR-1	
VESTAX	VCI300	
VESTAX	VCI300mk2	
VESTAX	VCI100mk2	
VESTAX	TYPHOON	
VESTAX	SPIN	
VESTAX	PMC05pro4 (MIDI button)	

BRAND	MODEL	
M-Audio	key station mini32	
Numark	MIXTRAX	
Numark	MIXTRAX PRO	
Numark	iDJ3	
Numark	N4	
Numark	Stealth Control	
ION	DISCOVER DJ	
Presonus	FaderPort	
Pearl	R.E.D. Box	